



Mantel Installation Instructions

(Page one)

- Remove old fireplace mantel (if applicable)
- Ensure surface is smooth and free from dust and debris
- Assemble all required tools and products necessary for installation (see list)
- Dry-fit *Mission Stone* mantel
 - Ensure legs are plum
 - Level mantel
 - Check that sufficient space exists between fireplace opening and *Mission Stone* surround
 - Make sure you follow all local building and fire codes



- Use a pencil to mark a line on the wall to use as a guide when installing mantel surround
- Take *Mission Stone* mantel down
- Re-verify with 6' level, that links are plum and level



- Use liquid nails Construction adhesive
 - With a ¼" opening in tip of tube apply to one leg
 - Press firmly against wall and floor (hearth) ensuring leg is aligned with plum line

Mantel Installation Instructions

(Page two)



- Follow adhesive manufacturer's recommendations for use
- Repeat process for second leg
- Allow time to dry
- Apply adhesive to top of both legs
- Apply adhesive to mantel back



- Lift mantel into place and press firmly to wall and down on legs
- Check for level
- Allow time to dry
- Use a 1 x 2 to firmly press mantel to wall (remove after 24-48 hrs)
- Use sanded caulk and apply a 1/8" bead where mantel and legs meet wall



- Wipe with a wet finger to ensure a smooth bead
- Wipe wall and mantel clean with a damp sponge.